1 Driver Installation procedure

1. Download the Cisco_usbconsole_driver_3_1.zip file and unzip it.
2. Double click setup(Win2k).exe, and follow the steps as shown on following sections.

1.1 Install / Uninstall Cisco USB console serial drive on W2K

1.1.1 Install

Run the setup(Win2k).exe program
Click Next on the Dialog to proceed with installation program

.

Attach the device: Connect the USB cable to Router, a series of Info Messages Boxes will pop-up automatically. After the last of these Info Message Boxes disappeared, the usbconsole feature is ready to be used.

Found New Hardware

◇   Cisco USB Console

Please wait ...

Found New Hardware

◇   Cisco USB to Serial adapter

Installing ...

Found New Hardware

     Cisco Virtual Comm Port00

Please wait ...

Found New Hardware

     Cisco Serial

Installing ...

1.1.2 W2k uninstallation

Go to "Add or Remove Programs" or setup.exe for driver un-installation with or without device attached. Note that if the COM port is still open by Windows 's hyper-terminal program, please CLOSE hyper-terminal during un-installation. Please follow the reminder to restart the computer for completion.

Following is an example of W2k uninstallation steps for both "Add/Remove program" and "setup(Win2k).exe program" :

.

Welcome to the InstallShield Wizard for Cisco Virtual Com

The InstallShield(R) Wizard will allow you to modify, repair, or remove Cisco Virtual Com. To continue, click Next.

Program Maintenance

Modify, repair, or remove the program.

○ **Modify**

Change which program features are installed. This option displays the Custom Selection dialog in which you can change the way features are installed.

○ **Repair**

Repair installation errors in the program. This option fixes missing or corrupt files, shortcuts, and registry entries.

● **Remove**

Remove Cisco Virtual Com from your computer.