

Cisco Systems, Inc.

USB Console drivers Installation notes for PC with Windows 64bits OS.

Introduction:

For users with following MS OS who would like to install Cisco USB console driver on their PC:


- Windows XP Professional x64 Edition, see installation guide on section 1.
- Windows Vista Business 64-bits, see installation guide on section 2.

Note: Windows Vista 64 requires that all drivers are signed.


Installations:

1. Windows XP Professional x64 Edition Installation Procedure:


- Double click on setup(x64).exe to start installation process



- Follow instruction on message window to proceed



- The installation should continue successfully, click on Finish to close message window.




The driver is now installed. User can choose a terminal emulation program to access the router


2. Windows Vista Business 64-bits Installation Procedure:

Vista 64 requires that all drivers are signed.


- Double click on setup(x64).exe to start installation process



- Follow instruction on message window to proceed



- A User Account Control could pop up asking user to proceed or cancel the program.
- Click on “Allow – I trust this program. I know where it ‘s from or I ‘ve used it before” to proceed.



- The installation should continue successfully, click on Finish to close message window.
- Connect the router to PC, a message box on top of the system tray will indicate the driver installation progress. Once it is finished, user can choose a terminal emulation program and access the router.